

- •PS/2 Fully Compatible Slim Design Switch Reliability: 5 millions
 - Provides 3 ACPI Power Management Keys
 - Windows 95/98SE/2000/ME/XP/NT Compatible



Challenge The Limit

PKB9801 MULTIMEDIA KEYBOARD

Features & Benefits

- Dimension: 471(L)x212(W)x48(H) mm
- Windows 95/98/ME/2000/NT/XP compatible
- PC PS/2 fully compatible
- Designed for enhanced Windows 95/98/2000 key layout
- High quality membrane tactile key switch available
- Switch reliability: 5 millions
- Provides three ACPI power management keys
- With special driver installation needed (Except Windows ME/XP)

Provides 18 Internet/Media Hot Keys

- Sleep: On computers with a power management program, the "Sleep" Hot Key enables you to Start your screen saver /
- Log off Windows / Shut down Windows.
- Wake Up: On computers with a power management program, the "Wake up" Hot Key enables you to restore, or wake up your computer.
- Power: On computers with a power management program, the "Power" Hot Key enables you to: Log off Windows / Shut down Windows.
- Back: Press this button to go to previous page.
- Forward: Press this button to go to next page.
- Stop Press this button to stop current transmission.
- Refresh Press this button to update the current page.
- Search Press this button to bring up " Search Windows " for Web address; Press this button again to close " Search
- Favorites Press this button to bring up " My Favorite Window " . Press this button again to close " My Favorite Window ".
- Web/Home Press this button to go to the default Home Page.
- Mail Press this button to activate the e-mail system.
- Mute Press this button to mute sound. Press it again to resume sound.
- Volume Press this button to decrease volume.
- + Volume Press this button to increase volume.
- Previous Press this button to set media back by one track. During playback of a video file, depress this button to cause the player to rapidly reverse it's playback direction. Press this button once to skip back to the beginning of current track. Press this button twice to skip back to the beginning of previous track.
- Stop Press this button to stop playing the media.
- Play/Pause Press this button to begin playing a CD or a video file (or to restart after pause). During playback press this key to pause the playback, press it again to resume playback on current position.
- Next Press this button to instruct the CD player to queue up beginning of the next track. During playback in a video file. Depress this button to cause the player to fast forward.
- Media Press this button to activate "Windows Media Player"
- Calculator Press this button to activate "Windows Calculator".
- My computer Press this button to open " My computer ".

Singapore

FIDA INTERNATIONAL (S) PTE LTD

Blk 105 Boon Keng Road #06-11/13 Kallang Basin Industrial Estate Singapore 339776

Tel: (65) 6392 5567 Fax: (65) 6392 5455 Website: www.fida.com

Malaysia

FIDA SYSTEMS (M) SDN BHD

29 USJ 1/31 47600 Subang Jaya Selangor Darul Ehsan Malaysia

Tel: (603) 8024 9151 Fax: (603) 8024 9161 Website: www.fida.com

http://www.fida.com

PROLINK is manufactured under the authority of FIDA INTERNATIONAL (S) PTE LTD

















prior notice



*Specifications are subjected to change without

Free Lifetime Technical Support Hotline

9am - 5.45pm (MON-FRI) 9am - 1pm (SAT)

Closed on Sundays & Public Holidays Tel: (65) 6296 5455 (SINGAPORE) (603) 8024 9151 (MALAYSIA)

All brand or product names are trademark or registered trademarks of their respective owners © Copyright 2004 PROLINK All Rights Reserved