

PROLINK®

Challenge The Limit

PKB9801-01

MULTIMEDIA KEYBOARD



- PS/2 Fully Compatible • Slim Design • Switch Reliability: 5 millions
- Provides 3 ACPI Power Management Keys
- Windows 95/98SE/2000/ME/XP/NT Compatible

PROLINK®

Challenge The Limit

PKB9801-01 MULTIMEDIA KEYBOARD

Features & Benefits

- Dimension : 471(L)x212(W)x48(H) mm
- Windows 95/98/ME/2000/NT/XP compatible
- PC PS/2 fully compatible
- Designed for enhanced Windows 95/98/2000 key layout
- High quality membrane tactile key switch available
- Switch reliability : 5 millions
- Provides three ACPI power management keys
- With special driver installation needed (Except Windows ME/XP)

Provides 18 Internet/Media Hot Keys

- **Sleep:** On computers with a power management program, the "Sleep" Hot Key enables you to Start your screen saver /
- **Log off** Windows / Shut down Windows.
- **Wake Up:** On computers with a power management program, the "Wake up" Hot Key enables you to restore, or wake up your computer.
- **Power:** On computers with a power management program, the "Power" Hot Key enables you to : Log off Windows / Shut down Windows.
- **Back:** Press this button to go to previous page.
- **Forward:** Press this button to go to next page.
- **Stop** Press this button to stop current transmission.
- **Refresh** Press this button to update the current page.
- **Search** Press this button to bring up " Search Windows " for Web address ; Press this button again to close " Search Windows ".
- **Favorites** Press this button to bring up " My Favorite Window " . Press this button again to close " My Favorite Window ".
- **Web/Home** Press this button to go to the default Home Page.
- **Mail** Press this button to activate the e-mail system.
- **Mute** Press this button to mute sound. Press it again to resume sound.
- **- Volume** Press this button to decrease volume.
- **+ Volume** Press this button to increase volume.
- **Previous** Press this button to set media back by one track. During playback of a video file, depress this button to cause the player to rapidly reverse it's playback direction. Press this button once to skip back to the beginning of current track. Press this button twice to skip back to the beginning of previous track.
- **Stop** Press this button to stop playing the media.
- **Play/Pause** Press this button to begin playing a CD or a video file (or to restart after pause). During playback press this key to pause the playback, press it again to resume playback on current position.
- **Next** Press this button to instruct the CD player to queue up beginning of the next track. During playback in a video file. Depress this button to cause the player to fast forward.
- **Media** Press this button to activate " Windows Media Player ".
- **Calculator** Press this button to activate "Windows Calculator ".
- **My computer** Press this button to open " My computer ".

Singapore

FIDA INTERNATIONAL (S) PTE LTD

Blk 105 Boon Keng Road #06-11/13

Kallang Basin Industrial Estate

Singapore 339776

Tel: (65) 6392 5567 Fax: (65) 6392 5455

Website: www.fida.com

Malaysia

FIDA SYSTEMS (M) SDN BHD

29 USJ 1/31

47600 Subang Jaya Selangor

Darul Ehsan Malaysia

Tel: (603) 8024 9151 Fax: (603) 8024 9161

Website: www.fida.com

**Specifications are subjected to change without prior notice*

<http://www.fida.com>

PROLINK is manufactured under the authority of **FIDA INTERNATIONAL (S) PTE LTD**



All brand or product names are trademark or registered trademarks of their respective owners
© Copyright 2004 PROLINK All Rights Reserved

Online Technical Support
support@fida.com

Free Lifetime Technical Support Hotline

9am - 5.45pm (MON-FRI)

9am - 1pm (SAT)

Closed on Sundays & Public Holidays

Tel: (65) 6296 5455 (SINGAPORE)

(603) 8024 9151 (MALAYSIA)